ROVERKORD INSTALLATION STEPS PAPER

Printable setup checklist for roof platforms, cargo boxes, awnings, ladders, and mounting hardware.

1. UNBOX

Confirm product, brackets, fasteners, rubber pads, and included tool kit before placing anything on the vehicle.

2. PREPARE

Clean mounting points. Identify factory rails, clamps, T-slots, or vehicle-specific feet. Keep paint protected.

3. MOUNT

Seat brackets evenly. Align the rack, awning case, cargo box, ladder, or accessory before final tightening.

4. TIGHTEN

Tighten all hardware gradually in sequence. Follow the vehicle and product torque specification where supplied.

5. CHECK

Inspect clearance, door swing, wind fairing position, cable routing, and accessory stability before driving.

QUICK SAFETY CHECKLIST

- Hardware is seated and tightened in a balanced sequence.
- Load does not exceed vehicle dynamic and static limits.
- No drilling unless the vehicle-specific guide requires it.
- Re-check fasteners after the first drive and after rough roads.
- Contact support if fitment, wind noise, or part identification is uncertain.

Support: support@roverkord.com Phone: +86 757 8880 8888

This paper is a general checklist. Always follow product-specific instructions and vehicle limits.